


 · © 2026 INTER-TOOL LLC. All rights reserved.

DS3011 PARTS LIST 2026

FIG.	PART NO. LIST	DESCRIPTION	NO. REQ.	NOTE
1	IPT-DS01 ASM	Aluminum Base w/chain	1	
2	FE-14-25E110	Fein Motor 110V 60Hz with 5/8"-11 thread spindle	1	
3	IPT-DS03	Round Head Screw 10-24X1-1/4"	3	
4	IPT-DS04	External Snap Ring for ER24 Bearing	1	
5	IPT-DS05	Sprocket with 5/8"-11 threads	3	
6	IPT-DS06	Plastic Spur Gear	1	
7	IPT-DS07	Steel Spur Gear with 5/8"-11 Threaded Bore	1	
8	IPT-DS08	Plastic Cover Ring	1	
9	IPT-DS09	Socket Head Cap Screw 1/4-20x2.0" SS	5	
10	IPT-DS10	Cover Plate	1	
11	IPT-DS11	Flat Head Tapping Screw 10x1.0" SS	3	
12	IPT-DS12	Rigid Back Up Pad 5" with 5/8"-11 Threaded Bore	3	
14	IPT-DS14	External Snap Ring for ER12 Bearing	3	
15	IPT-DS15	Ball Bearing ER12	3	
17	IPT-DS17	Center Ball Bearing ER24	1	
18	IPT-BHA	Garden Hose Adapter	1	
19	IPT-JGA	Hose Fitting	3	
20	IPT-CT14	Water Hose	8 ft	
21	IPT-DS21	Brass Ball Valve	1	
22	IPT-DS22	Steering Wheel Cap	4	
23	IPT-DS23	Rubber-Cushioned Clamp (water valve)	1	
24	IPT-DS24	Binding Head Screw 1/4-20x1/2" SS	6	
26	IPT-DS26	Steering Wheel	1	
28	IPT-DS301128	Vacuum Adapter 2-1/2"	1	
29	IPT-DS301129	Slurry Skirt 44"	1	
35	FE-CB14-25	Carbon Brushes for #2 Motor (Not shown)	1 pair	
36	IPT-DS36	WPO14-25E Air Adapter	1	

 © 2026 INTER-TOOL LLC. All rights reserved.